

Cleaning spray for garden tools, 500ml

Keep your tools and garden machines in top condition with minimal effort.

Grimsholm cleaning spray cleans gently and effectively by dissolving dried grass and dirt.

An effective, gentle and environmentally friendly cleaning product specially developed to keep your robotic lawn mower and other garden machines and tools in top condition.

The alkaline cleaning solution contains non-ionic surfactants that effectively dissolve and remove grass residues, soil, and other contaminants without damaging your equipment.

Preprocessing

Make sure the robotic lawnmower is turned off.
Remove loose contaminants as much as possible.

Application and use

- Read the instruction manual for cleaning the machine or tool in question.
- Shake the bottle well before use.
- Spray directly onto the dirty surface.
- Leave on for 5-10 minutes to dissolve dirt and fat.
- Do not allow the cleaner to dry before wiping it off.
- Scrub if necessary with a brush or sponge.
- Rinse off with water and wipe with a clean cloth.



Technical data

Assortment/Item #6605

Produktinnehåll	Water, non-ionic surfactants and sodium hydroxide
Colour	Clear liquid
Storage	Should be consumed within 36 months. Preferably stored at a temperature of 5-23°C
Protective Precautions	The product is corrosive